

New Cat Condos

Assembly Instructions

Premier Designer Cat Pagoda SKU: 110059

Package contents:

- 1 - Assembled Pagoda Tree without stairs
- 1 - Separated Stairs
- 3 - Wood screws (Drilled into middle Perch)

Required tools:

- 1 - Power drill (a hand screwdriver can be used but is not recommended)

Follow these easy steps:

- 1** In a large, open area, open the box and remove all contents
- 2** Place the stairs with the exposed wood side up and line them up with the wood screws of the Assembled Pagoda Tree
- 3** Drill each screw into the wood Stairs until they are flush against the wood and the stair is secure.
- 4** **OPTIONAL:** If you find the above method is difficult, you may use 2 inch or larger nails with flat tops (not included). Place them in the same positions as the screws and use a hammer to nail them down until they are flush with the bed surface.

