

# New Cat Condos

## Assembly Instructions

### Premier Cat Bungalow Cat Tree SKU: 110093

#### Package contents:

- 1 - Cat Tree with Lower Perch and attached house
- 1 - Separate perch with screws driven into it
- 3 - Wood Screws (Screwed into Top Perch)

#### Required tools:

- 1 - Power drill (a hand screwdriver can be used but is not recommended)

#### Follow these easy steps:

- 1** In a large, open area, open the box and remove all contents
- 2** Place the single perch on the tallest post. Be sure to line up the wood screws to the center of the exposed wood post.
- 3** Drill each screw into the post until they are flush against the bed and the bed is secure.
- 4** **OPTIONAL:** If you find the above method is difficult, you may use 2 inch or larger nails with flat tops (not included). Place them in the same positions as the screws and use a hammer to nail them down until they are flush with the bed surface.

