

New Cat Condos

Assembly Instructions

Premier Double Perch Solid
Wood Cat Condo
SKU: 110036



Package contents:

- 1 - Previously assembled stand
- 2 - Separate perches with pre-drilled screw holes
- 6 - Packaged wood screws

Required tools:

- 1 - Power drill (a hand screwdriver can be used but is not recommended)

Follow these easy steps:

1

In a large, open area, open the box and remove all contents

2

Place the single perch on the first post. Be sure to line up the three pre-drilled screws with the post

3

Drill each screw into the post until they are flush against the bed and the bed is secure. Repeat for both perches.

4

OPTIONAL: If you find the above method is difficult, you may use 2 inch or larger nails with flat tops (not included). Place them in the same positions as the screws and use a hammer to nail them down until they are flush with the bed surface.

