

# Prestige Cat Trees

## Assembly Instructions



### Package Includes

- 1 Base
- 1 Cave
- 1 Circular Perch
- 1 Crescent Perch with Post
- 1 Single Post with Rope
- 1 Big Tunnel with Crescent Perch



### Required Tools

Power drill (a hand screwdriver can be used but is not recommended)

### Assembly Steps

- 1** Take the Circular Perch & in a clockwise rotation screw it onto the single post at the bottom of the base (see figure 1).  
**(DO NOT OVERTIGHTEN)**
- 2** Take the Cave & in a clockwise rotation screw it onto the middle of the base (see figure 2).  
**(DO NOT OVERTIGHTEN)**
- 3** Take the Crescent Perch with Post & in a clockwise rotation screw it to the left hole of the base (see figure 3).  
**(DO NOT OVERTIGHTEN)**
- 4** Take the Single Post with Rope & in a clockwise rotation screw it to the right hole of the base (see figure 4).  
**(DO NOT OVERTIGHTEN)**
- 5** Take the remaining Big Tunnel & screw it to the top of the Roped post in a clockwise manner (see figure 5).  
**(DO NOT OVERTIGHTEN)**
- 6** Take the two provided screws & drill them through the corner of the cave onto the Roped post.

